

Vehicle tracking

Installation guide: atom-h

Before proceeding, ensure you have access to any tools required to complete a hardwired device installation.



Step 1

Remove center console.

Step 2

Test your wires before making any connections. Constant wire should receive 12v while your vehicle is off.

Step 3

Connect crimps to the source wires. Make sure they make a solid connection and do not pull off easily.

Step 4

Strip the red, black and brown wires on GPS harness.

Step 5

Connect wires to their corresponding wires.

Step 6

Secure the device to the vehicle and put everything back together.

Note

Connect black wire to ground, connect red wire to 12+V. Optional: Connect brown wire to ignition. Device will start blinking red. Wait for device to blink green.

Need help?

If you have any questions or require assistance, please contact our team on **+1 888 278 9781**.